



INSTALLATION INSTRUCTIONS FOR THE U.M.I. YAMAHA SUPERJET HANDLEPOLE SPRING

SPRING REMOVAL:

1. Remove hood.
2. Lock handlepole in the up position.
3. Remove the two Phillips screws and remove the front cowling.
4. Remove the 22mm jam nut and primary nut off of the handlepole bolt.
5. Using a combination of unscrewing (counter clockwise) the handlepole through bolt and tapping the threaded end with a flat punch; slide bolt back just far enough to remove the stock springs.
6. Remove the two stock handlepole springs.

SPRING INSTALLATION:

1. Installation of the new U.M.I. Racing handlepole spring is easiest if performed from the left side of the hull.
2. Hold the spring in your hand so the red cap on the L-shaped end faces left and the red cap on the opposite end faces to the right, and install spring inside the handlepole to the left of the rubber cable boot.
3. Slide the handlepole bolt through the crown, handlepole and into the coils of the spring. Lubricate the handlepole through bolt, handlepole bushings, and spring coils to aid in the installation.
4. Using a combination of screwing (clockwise) and tapping with a mallet carefully slide bolt through the spring coils and into the opposite side of the handlepole and crown. Pay attention to which way the spring needs to be pushed or pulled while sliding bolt through, in order to keep the threads from being damaged.
5. Re-fasten primary and jam nut onto the through bolt.
6. Install front cowling.

Installation is complete. You now have a feather light handlepole.

Thank you for choosing U.M.I. Racing products. If you have any questions please call us at 800-275-1615.